

Steps to Paint Bare Wood

Objective: The following steps will provide instructions on how to prepare bare wood for painting and to select the optimal painting tools to complete your desired project.

1. Sand the surface

- Stock lumber is often coated in a glaze to protect it. Removing the coating will help the paint to adhere to the wood.
- Sanding opens the grain of the wood, which helps with adhesion.

2. Seal the knots with a primer

- This step will prevent the stain of a knot from bleeding through the paint.
- It is recommended that an oil-based spray primer is used for ease in clean-up.

3. Smooth the surface

- Use a dedicated primer. They have higher concentrations of solids versus a paint and primer in one. This will better fill the grain for a smoother topcoat.
- It's normal for the first couple of coats to appear uneven. Bare wood loves to soak up paint.
- Once dry, lightly sand the surface between each coat to knock down the grain, which raises from the moisture.

4. Consider a tinted primer

- A brightly colored paint or a darker toned paint over a primer will achieve its final hue with less coats.

5. Choose a color base

- Consult a paint expert for recommendations on the correct base for your desired paint color before tinting.

Process to Paint Bare Wood

